





## LUBRICATION

TWICE DAILY  
(More Frequently  
With Severe use)


Use white spindle oil. When starting the machine initially and after kept away for a long time without using at all, oil sufficiently to respective necessary before starting operation and pre-running.  
Open A, B and C, oil to respective necessary parts and parts indicated by arrow marks.



SKZ type



SKM type



# SEIKO

SKZ-6


SKZ-6R

SKM-26


SKM-36

## NEEDLE


Move needle bar to highest point.  
Loosen needle set screw.  
Insert needle up as far as possible and tighten screw. Long groove towards operator.




## THREADING NEEDLE



NEEDLE Move needle bar to highest point.  
Loosen needle set screw. Insert needle up as far as possible and tighten screws.



## THREADING NEEDLE




SEIKO SEWING MACHINE CO., LTD.


11-3, Imado 1-chome, Taito-ku, Tokyo, 111-8534 Japan

Tel: (03) 3872-6173~4


## BOBBIN REMOVAL



## BOBBIN CASE REPLACEMENT




## THREAD TENSIONS




Tension on threads should be as light as possible, while still sufficient to set stitch correctly in material.


## PRESSER FOOT PRESSURE




## WINDING THE BOBBIN




## SWITCH WIDTH




## THREAD TENSION



## NEEDLE THREAD



## THREADING BOBBIN CASE



## CHANGING STITCH LENGTH

