


SEIKO

PARTS LIST FOR MODELS


CW-1, 7, 7B, 8, 8B, 8V, 8BV
LCW-7, 7B, 8, 8B, 8V, 8BV, 6F
CYLINDRICAL BED MACHINES




SEIKO SEWING MACHINE CO., LTD.
TOKYO · JAPAN

INDEX

	Page
Thread take up lever, needle bar for all models	1
天秤・針棒関係	
Arm shaft, feeding mechanism for CW.LCW-7, 8 & 8V	2
CW・LCW-7, 8 & 8V 上軸・送り機構関係	
Lifting lever, face plate, slide plate for all models	3
弓、面板、差し板、ベース関係	
Presser bar, lifting rock shaft, vibrating presser foot for CW.LCW-8, 8B, 8V & 8BV . . .	4
CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係	
Hook driving shaft, rotating hook, timing belt for all models	5
下軸、カム関係	
Thread tension, feed driving rock shaft, feeder, needle plate for all models	6
糸掛、糸調子、送り竿関係	
Accessories	7
附属関係	
Reverse stitch mechanism for CW.LCW-7B, 8B & 8BV	8
CW・LCW-7B・8B&8BV バック関係	
Special parts for CW.LCW-8V & 8BV	9
CW・LCW-8V&8BV 専用部品	
Presser bar, needle bar, needle plate, feeder for CW.LCW-7 & 7B	10
CW・LCW-7 & 7B 針棒・押え棒関係	
Special parts for LCW	11
LCW 専用部品	
Special parts for CW-1	12
CW-1 専用部品	
Belt guard	13
ベルトガード	
Special parts for LCW-6F	14
LCW-6F 専用部品	
Feed mechanism for LCW-8B	15
LCW-8B 送り関係	



Model CW-8V




Model LCW-8B

Exploded view diagram of a mechanical assembly. The diagram shows various components and their assembly relationships, indicated by dashed lines and arrows. The parts are labeled with numbers and codes:

- Top Left:** $\Delta\phi 10525$, $\Delta\phi 10726$
- Top Center:** $\Delta\phi 10701-A$, 10725, 10729, 10563
- Top Right:** 13084, 13058, 13057, 10562
- Middle Left:** 10551, 10650, $\Delta x 10525$, $\Delta x * 15110-A$, $\Delta x 11875$
- Middle Center:** 10728, 19416, 19415, 19414, 19417, $\phi 19418$, 10526C, $x 10726$
- Middle Right:** 10726, $\Delta x 10578$, $\Delta x * 19426$, $\Delta x * 13365$, $\Delta x 10560$, $x 10561$
- Bottom Left:** $\Delta x *$, 15117, $\Delta x *$, 15118
- Bottom Center:** $\Delta ox * 19413$, $\Delta ox * 10533$, 6035, B140553
- Bottom Right:** $\Delta x 13364$, $\Delta x 19408$, $\Delta x 10728$, $\Delta x 16706$, $\Delta x 13363$, $\Delta x 13071$

Parts marked * are not necessary for CW-7 & 7B
 Parts marked O are not necessary for LCW
 Parts marked X are not necessary for CW-1
 Parts marked Δ are not necessary for LCW-6F

(*印は CW-7, CW-7B には不要)
(○印は LCW タイプには不要)
(×印は CW-1 には不要)
(△印は LCW-6F には不要)



3

弓, 面板, 差し板, ベース関係

LIFTING LEVER, FACE PLATE, SLIDE PLATE FOR ALL MODELS EXCEPT PARTS MARKED O.X.*

10712

13056-A

13059

10707

10706

10705

13079A

10699

10704

10703

x10702

13440
37100

13440 37100 13005

x10698

13004
13436

10700

13027

13026

13024

13025

13027

x13009

13089

13438 882
13383

19403

13006


13388-A

13008

Parts marked * are not necessary for CW.LCW-8V & 8BV (*印は CW・LCW-8V & 8BV には不要)
Parts marked O are not necessary for LCW (O印は LCW には不要)
Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)


CW・LCW-8, 8B, 8V, & 8BV 押え棒・横軸・中押え関係
 PRESSER BAR, LIFTING ROCK SHAFT, VIBRATING PRESSER
 FOR CW・LCW-8, 8B, 8V & 8BV

4



Parts marked * are not necessary for CW・LCW-8V & 8BV (*印は CW-8V, CW-8BV, LCW-8V, LCW-8BV には不要)
 Parts marked O are not necessary for LCW (O印は LCW には不要)


HOOK DRIVING SHAFT, ROTATING HOOK, TIMING BELT FOR ALL MODELS EXCEPT PARTS MARKED *. +. -. X. Δ



Part marked * is not necessary for CW, LCW-7B, 8B & 8BV
 Part marked + is for only CW, LCW-7B, 8B & 8BV
 Part marked - is not necessary for CW, LCW-8V & 8BV
 Parts marked X are not necessary for CW-1
 Parts marked Δ is for only LCW-6F


(*印は CW・LCW-7B, 8B & 8BV には不要)
 (+印は CW・LCW-7B, 8B & 8BV にのみ)
 (-印は CW・LCW-8V & 8BV には不要)
 (X印は CW-1 には不要)
 (Δ印は LCW-6F のみ)

THREAD TENSION, FEED DRIVING ROCK SHAFT, FEEDER, NEEDLE PLATE FOR ALL MODELS EXCEPT PARTS MARKED * . + . ○ . X . △




Parts marked * are not necessary for CW . LCW-7 . 7B . 8V & 8BV (*印は CW・LCW-7, 7B, 8V&8BV には不要)
 Parts marked + are not necessary for CW . LCW-8V & 8BV (+印は CW・LCW-8V&8BV には不要)
 Parts marked ○ are not necessary for LCW (○印は LCW には不要)
 Parts marked X are not necessary for CW-1 (X印は CW-1 には不要)
 Parts marked △ are not necessary for LCW-6F (△印は LCW-6F には不要)

ACCESSORIES FOR ALL MODELS




8132A

10656


N0122
X-N0618
N0118

10748



35254

10734



8118C

8123
O 11193

*11969

11487




10709




8124



13096



13094



Part marked X is used for only CW-1

Part marked O is used for only LCW

Part marked * is used for only CW, LCW-7B, 8B & 8BV


(X印は CW-1のみ)

(O印は LCWのみ)

(*印は CW, LCW-7B, 8B&8BVのみ)

CW・LCW-7B・8B&8BV バック関係
 REVERSE STITCH MECHANISM FOR
 CW・LCW-7B, 8B & CW-8BV

8



13423-B A ... Use with guard A ... ガード付用
 B ... Use without guard B ... ガード無用

CW · LCW- 8 V & 8 BV 専用部品
SPECIAL PARTS FOR CW · LCW – 8V & 8BV


13246

13249



13234

13235



11823 8086-02



13240





13221C



10561



13235



13256

13243



13216



13252



13212

13213



13207



13208

13209



2067

2067

10545

13206



13204



8111


10659



13253



13383



13263


11830




13261



13264




13260




CW・LCW-7 & 7B 針棒・押え棒関係
 PRESSER BAR, NEEDLE BAR, NEEDLE PLATE, FEEDER
 FOR CW・LCW-7 & 7B

10



LCW 専用部品

SPECIAL PARTS FOR LCW



Parts marked * is used for only LCW-7, 7B

Parts marked + is used for only LCW-8, 8V, 8B & 8BV

Parts marked Δ is not necessary for LCW-6F


(*印は LCW-7, 7B のみ)

(+印は LCW-8, 8V, 8B & 8BV のみ)

(Δ印は LCW-6F には不要)


CW-1 専用部品
SPECIAL PARTS FOR CW-1

12



NOTE) 13423 A ... Use with guard B ... Use without guard (注) 13423

A ガード付用
B ガード無用



○ 10559
○ 11162




Parts marked ○ are not used CW, LCW-7, 8 & 8V.
Parts marked * are used for only CW, LCW-7, 8 & 8V.
Parts marked △ are used for only LCW-6F.

(○印は CW・LCW-7、8 & 8V には不要)
(*印は CW・LCW-7、8 & 8V のみ)
(△印は LCW-6F のみ)

LCW - 6F 専用部品
SPECIAL PARTS FOR LCW - 6F

14



LCW-8B 送り関係

FEED MECHANISM FOR LCW - 8B

