

For Beautiful Stitching on Fine Leathers







PRODUCT INFORMATION

ORGAN® NEEDLES CUTTING POINT Series

A wide variety of designs are possible

Straighter Stitching

With the new improved design, the needle is stronger. Furthermore needle deflection that causes skipped stitched has been significantly reduced.



Consistant Loop Formation

For consistant loop formation, we adapted our unique Cliff Scarf to make enough space between the thread and needle.



Thick Threaded Designs possible

By making the needle eye bigger, the normal flament thread #5 can now be used with needle size #21. As well flament thread #0 can be used with needle size #23.



NORMAL							Emiliar des
SYMBOL	- \ LL	-D+ LR	S	P	D D	→ D I	- (→)→ TQ
POINT							
STITCH							

Introducing the new expanded lineup of small cutting point

SMALL C	CUTTING POIN	Г(М)				
SYMBOL	→ M-LL	- Ø → M-LR	- M-S	M-P	→ M-D	M-DI
POINT		W			V	4
STITCH						

Packaging

-10pcs-DP x 17LL Size 21M

CUTTING POINT Series

SYSTEM	7	8	9	10	11	12	13	14	16	18	19	20	21	22	23	24	25	FORMER SYSTEM
DP×17LL*																		DP×16N
DP×17LR*																		DP×16LR/DP×17LR
DP×17S																		
DP×17P*																		DP×16
DP×17DIA*																		DP×17DIA
DP×17TQ																		
DP×35LL										•								
DP×35LR																		
DP×35S																		
DP×35P																		
DP×35D																		
DP×134LL*																		PF×134LL
DP×134LR*	0																	PF×134LR
DP×134S*							RC#											PF×134KS
DP×134P*						EC.												PF×134P
DP×134DIA*						NO.												DP×8
DP×134D*		EOM:					KON		EO.									PF×134D

^{*} Please Note: we have renamed the system.



ORGAN NEEDLE CO., LTD.

Business Development Center

1160 Aokubo, Ueda-shi, Nagano-ken 386-0155, Japan www.organ-needles.com E-mail:sales-dpt@organ-ndl.co.jp



^{*}The arrows show the direction to thread the needle

^{*}When placing an order for the small cutting point, please indicate with an M after the size number.